

Samsung Galaxy smartphones supporting My Knox	
Galaxy A9 (2016), A8, A7 (2016), A7, A5 (2016), A5, A3 (2016), A3	Availability of My Knox may vary depending on your region, mobile service provider, etc.
Galaxy Alpha	
Galaxy E7, E5	
Galaxy Folder	
Galaxy J7, J5 (2016), J5, J3 (2016), J	
Galaxy Note 7, Note 5, Note 4, Note 3, Note 3 Neo, Note Edge	
Galaxy On7	
Galaxy S7, S7 edge	
Galaxy S6, S6 active, S6 edge, S6 edge+	
Galaxy S5, S5 Active, S5 LTE-A, S5 mini, S5 Neo, S5 Sport	
Galaxy S4	
Galaxy Xcover 3	
心系天下 W2016 (SM-G9198)	
领世旗舰3 (SM-W2016)	
Galaxy Note 10.1 (2014 edition)	
Galaxy Tab 4, Tab A (8.0, 9.7, 10.1), Tab Active, Tab E (8.0), Tab S2 (8.0, 9.7)	

Samsung Galaxy smartphones supporting Knox		
Model	Model Number	Knox Version
Galaxy A9	SM-A9000	Knox 2.6
	SM-A9100	Knox 2.6
	SM-A910F	Knox 2.6
Galaxy A8	SM-A8000	Knox 2.4
	SM-A800F	Knox 2.6
	SM-A800I	Knox 2.6
	SM-A800J	Knox 2.4
	SM-A800S	Knox 2.4
	SM-A800YZ	Knox 2.4
	SM-A7000	Knox 2.4
Galaxy A7	SM-A7009	Knox 2.4
	SM-A700F	Knox 2.6
	SM-A700FD	Knox 2.6
	SM-A700H	Knox 2.4
	SM-A700K	Knox 2.4
	SM-A700L	Knox 2.4
	SM-A700S	Knox 2.4
	SM-A700YD	Knox 2.4
	SM-A7100	Knox 2.5.1
	SM-A710F	Knox 2.6
	SM-A710K	Knox 2.6
	SM-A710L	Knox 2.6
	SM-A710M	Knox 2.6
	SM-A710S	Knox 2.6

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy A5	SM-A5000	Knox 2.4
	SM-A5009W	Knox 2.4
	SM-A500F	Knox 2.4
	SM-A500F1	Knox 2.4
	SM-A500FU	Knox 2.6
	SM-A500H	Knox 2.4
	SM-A500K	Knox 2.4
	SM-A500L	Knox 2.4
	SM-A500M	Knox 2.4
	SM-A500S	Knox 2.4
	SM-A500XZ	Knox 2.1
	SM-A500Y	Knox 2.4
	SM-A5100	Knox 2.5.1
	SM-A510F	Knox 2.6
	SM-A510FD	Knox 2.6
	SM-A510K	Knox 2.6
	SM-A510L	Knox 2.6
	SM-A510M	Knox 2.6
	SM-A510S	Knox 2.6
Galaxy A3	SM-A3000	Knox 2.3
	SM-A3009	Knox 2.3
	SM-A300F	Knox 2.3
	SM-A300FU	Knox 2.6
	SM-A300H	Knox 2.3
	SM-A300M	Knox 2.3
	SM-A300XZ	Knox 2.1
	SM-A300Y	Knox 2.4
	SM-A300YZ	Knox 2.3
Galaxy A3 (2016)	SM-A310F	Knox 2.6
	SM-A310M	Knox 2.6
	SM-A310N0	Knox 2.6
Galaxy Ace Style	SM-G357FZ	Knox 2.2
Galaxy Alpha	SM-G850A	Knox 2.3
	SM-G850F	Knox 2.3
	SM-G850K	Knox 2.3
	SM-G850L	Knox 2.3
	SM-G850S	Knox 2.3
	SM-G850W	Knox 2.3
	SM-G850X	Knox 2.1
Galaxy C7	SM-C7000	Knox 2.6
Galaxy C5	SM-C5000	Knox 2.6
Galaxy Core Max	SM-G5108	Knox 2.1
	SM-G5108Q	Knox 2.1
	SM-G5109	Knox 2.1

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy Core Prime	SM-G360BT	Knox 2.3
	SM-G360F	Knox 2.3
	SM-G360FY	Knox 2.3
	SM-G360G	Knox 2.4
	SM-G360GY	Knox 2.4
	SM-G360M	Knox 2.3
Galaxy Core Prime Value Edition	SM-G361F	Knox 2.4
Galaxy E7	SM-E700F	Knox 2.4.1
	SM-E700H	Knox 2.4.1
Galaxy E5	SM-E500F	Knox 2.4.1
	SM-E500H	Knox 2.4.1
Galaxy Express 2	SM-G3815	Knox 2.1
Galaxy Folder	SM-G150N0	Knox 2.4
	SM-G150NK	Knox 2.4
	SM-G150NL	Knox 2.4
	SM-G150NS	Knox 2.4
	SM-G155S	Knox 2.4
	SM-G9198	Knox 2.4.1
Galaxy Golden	SM-W2015	Knox 2.1
	SM-W2016	Knox 2.5
Galaxy Grand 2	SM-G7102	Knox 2.1
	SM-G7105	Knox 2.1
	SM-G7105L	Knox 2.1
	SM-G7109	Knox 1.x
	SM-G710K	Knox 2.1
	SM-G710L	Knox 2.1
	SM-G710S	Knox 2.1
Galaxy Grand Prime	SM-G5306W	Knox 2.1
	SM-G5308W	Knox 2.1
	SM-G5309W	Knox 2.1
	SM-G530F	Knox 2.4
	SM-G530FZ	Knox 2.4
	SM-G530H	Knox 2.4
	SM-G530P	Knox 2.4
	SM-G530R4	Knox 2.4
	SM-G530R7	Knox 2.4
	SM-G530T	Knox 2.4
	SM-G530T1	Knox 2.4
	SM-G530W	Knox 2.4
SM-G530Y	Knox 2.1	
Galaxy Grand Prime Value Edition	SM-G531F	Knox 2.4
	SM-G531M	Knox 2.4
	SM-G531Y	Knox 2.4

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy J	SGH-N075T	Knox 2.3
Galaxy J7	SM-J7008	Knox 2.4
	SM-J700F	Knox 2.4
	SM-J700H	Knox 2.6
	SM-J700K	Knox 2.4
	SM-J700M	Knox 2.4
	SM-J700P	Knox 2.6
	SM-J700T	Knox 2.6
	SM-J700T1	Knox 2.6
	SM-J7108	Knox 2.5.1
	SM-J7109	Knox 2.5.1
	SM-J710FN	Knox 2.6
	SM-J710GN	Knox 2.6
	SM-J710K	Knox 2.6
	SM-J710MN	Knox 2.6
Galaxy J5	SM-J5008	Knox 2.4
	SM-J500F	Knox 2.6
	SM-J500FN	Knox 2.6
	SM-J500H	Knox 2.6
	SM-J500M	Knox 2.4
	SM-J500N0	Knox 2.4
	SM-J500Y	Knox 2.4
	SM-J5108	Knox 2.5.1
	SM-J510FN	Knox 2.6
	SM-J510GN	Knox 2.6
	SM-J510H	Knox 2.6
	SM-J510K	Knox 2.6
	SM-J510L	Knox 2.6
	SM-J510MN	Knox 2.6
SM-J510S	Knox 2.6	
SM-J510UN	Knox 2.6	
Galaxy J3 (2016)	SM-J3110	Knox 2.5.1
	SM-J3119	Knox 2.5.1
	SM-J320A	Knox 2.6
	SM-J3109	Knox 2.5.1
	SM-J320AZ	Knox 2.6
	SM-J320N0	Knox 2.6
	SM-J320P	Knox 2.5.1
	SM-J320R4	Knox 2.6
	SM-J320VPP	Knox 2.6
	SM-J320Y	Knox 2.5.1
	SM-J320YZ	Knox 2.5.1
	SM-J320ZN	Knox 2.5.1
SM-J321AZ	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy J2	SM-J200BT	Knox 2.4.1
	SM-J200F	Knox 2.4.1
	SM-J200G	Knox 2.4.1
	SM-J200GU	Knox 2.4.1
	SM-J200M	Knox 2.4.1
Galaxy J1	SM-J120A	Knox 2.6
	SM-J120AZ	Knox 2.6
	SM-J120F	Knox 2.5.1
	SM-J120FN	Knox 2.5.1
	SM-J120G	Knox 2.5.1
	SM-J120M	Knox 2.5.1
	SM-J120W	Knox 2.6
	SM-J120ZN	Knox 2.5.1
Galaxy Mega 6.3	GT-I9200	Knox 1.x
	GT-I9205	Knox 1.x
	GT-I9208	Knox 1.x
	SCH-R960	Knox 1.x
	SGH-I527	Knox 1.x
	SGH-I527M	Knox 1.x
	SHV-E310K	Knox 1.x
	SHV-E310L	Knox 1.x
	SHV-E310S	Knox 1.x
	SPH-L600	Knox 1.x
Galaxy Mega 2	SM-G7508Q	Knox 2.1
	SM-G750A	Knox 2.4.1
	SM-G750F	Knox 2.1
	SM-G750H	Knox 2.1
Galaxy Note 7	SM-N930A	Knox 2.7
	SM-N930F	Knox 2.7
	SM-N930K	Knox 2.7
	SM-N930L	Knox 2.7
	SM-N930P	Knox 2.7
	SM-N930R4	Knox 2.7
	SM-N930S	Knox 2.7
	SM-N930T	Knox 2.7
	SM-N930V	Knox 2.7
	SM-N930W8	Knox 2.7
Galaxy Note 5	SM-N9200	Knox 2.6
	SM-N9208	Knox 2.6
	SM-N920A	Knox 2.6
	SM-N920C	Knox 2.6
	SM-N920K	Knox 2.6
	SM-N920L	Knox 2.6
	SM-N920P	Knox 2.6
	SM-N920R4	Knox 2.6
	SM-N920S	Knox 2.6
	SM-N920T	Knox 2.6
SM-N920V	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy Note 4	SM-N910A	Knox 2.4.1
	SM-N910C	Knox 2.6
	SM-N910CQ	Knox 2.6
	SM-N910F	Knox 2.6
	SM-N910G	Knox 2.6
	SM-N910H	Knox 2.6
	SM-N910K	Knox 2.6
	SM-N910L	Knox 2.6
	SM-N910P	Knox 2.6
	SM-N910R4	Knox 2.6
	SM-N910S	Knox 2.6
	SM-N910T	Knox 2.6
	SM-N910T2	Knox 2.2
	SM-N910T3	Knox 2.6
	SM-N910U	Knox 2.6
	SM-N910V	Knox 2.6
SM-N910W8	Knox 2.6	
Galaxy Note 4 S-LTE	SM-N916K	Knox 2.6
	SM-N916L	Knox 2.6
	SM-N916S	Knox 2.6
Galaxy Note 3	SM-N900	Knox 2.3
	SM-N9005	Knox 2.3
	SM-N9008	Knox 2.3
	SM-N9008V	Knox 2.3
	SM-N900A	Knox 2.3
	SM-N900J	Knox 2.3
	SM-N900K	Knox 2.3
	SM-N900L	Knox 2.3
	SM-N900P	Knox 2.3
	SM-N900R4	Knox 2.3
	SM-N900S	Knox 2.3
	SM-N900T	Knox 2.3
	SM-N900V	Knox 2.3
SM-N900W8	Knox 2.3	
Galaxy Note 3 Neo	SM-N750	Knox 2.4.1
	SM-N7502	Knox 1.x
	SM-N7505	Knox 2.4.1
	SM-N7508V	Knox 1.x
	SM-N750K	Knox 2.4
	SM-N750L	Knox 2.4
	SM-N750S	Knox 2.4

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy Note 2	GT-N7100	Knox 1.x
	GT-N7105	Knox 1.x
	SCH-I605	Knox 2.0
	SCH-R950	Knox 1.x
	SGH-I317	Knox 1.x
	SGH-I317M	Knox 1.x
	SGH-T889	Knox 1.x
	SGH-T889V	Knox 1.x
	SHV-E250K	Knox 1.x
	SHV-E250L	Knox 1.x
	SHV-E250S	Knox 1.x
	SPH-L900	Knox 2.0
Galaxy Note Edge	SM-N915A	Knox 2.4.1
	SM-N915D	Knox 2.3
	SM-N915F	Knox 2.6
	SM-N915FY	Knox 2.6
	SM-N915J	Knox 2.3
	SM-N915K	Knox 2.6
	SM-N915L	Knox 2.6
	SM-N915P	Knox 2.6
	SM-N915R4	Knox 2.6
	SM-N915S	Knox 2.6
	SM-N915T	Knox 2.6
	SM-N915V	Knox 2.6
	SM-N915W8	Knox 2.6
	SM-N915X	Knox 2.6
Galaxy On7	SM-G600FY	Knox 2.4.1
	SM-G600F	Knox 2.6
	SM-G600S	Knox 2.6
Galaxy On5	SM-G550T	Knox 2.6
	SM-G550T1	Knox 2.6
	SM-G550T2	Knox 2.6
Galaxy Round	SM-G910S	Knox 1.x
Galaxy S7	SM-G9300	Knox 2.6
	SM-G930A	Knox 2.6
	SM-G930F	Knox 2.6
	SM-G930K	Knox 2.6
	SM-G930L	Knox 2.6
	SM-G930P	Knox 2.6
	SM-G930R4	Knox 2.6
	SM-G930S	Knox 2.6
	SM-G930T	Knox 2.6
	SM-G930U	Knox 2.6
	SM-G930V	Knox 2.6
SM-G930W8	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy S7 Active	SM-G891A	Knox 2.6
Galaxy S7 edge	SM-G9350	Knox 2.6
	SM-G935A	Knox 2.6
	SM-G935F	Knox 2.6
	SM-G935K	Knox 2.6
	SM-G935L	Knox 2.6
	SM-G935P	Knox 2.6
	SM-G935R4	Knox 2.6
	SM-G935S	Knox 2.6
	SM-G935T	Knox 2.6
	SM-G935U	Knox 2.6
	SM-G935V	Knox 2.6
	SM-G935W8	Knox 2.6
Galaxy S6	SM-G9200	Knox 2.6
	SM-G9208	Knox 2.6
	SM-G9209	Knox 2.6
	SM-G920A	Knox 2.6
	SM-G920F	Knox 2.6
	SM-G920FD	Knox 2.6
	SM-G920I	Knox 2.6
	SM-G920K	Knox 2.6
	SM-G920L	Knox 2.6
	SM-G920P	Knox 2.6
	SM-G920R4	Knox 2.6
	SM-G920S	Knox 2.6
	SM-G920T	Knox 2.6
	SM-G920T1	Knox 2.6
	SM-G920V	Knox 2.6
	SM-G920W8	Knox 2.6
SM-S906L	Knox 2.4	
Galaxy S6 active	SM-G890A	Knox 2.6
Galaxy S6 edge	SM-G9250	Knox 2.6
	SM-G925A	Knox 2.6
	SM-G925F	Knox 2.6
	SM-G925K	Knox 2.6
	SM-G925L	Knox 2.6
	SM-G925P	Knox 2.6
	SM-G925R4	Knox 2.6
	SM-G925S	Knox 2.6
	SM-G925T	Knox 2.6
	SM-G925V	Knox 2.6
SM-G925W8	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Model	Model Number	Knox Version
Galaxy S6 edge+	SM-G9280	Knox 2.6
	SM-G9287	Knox 2.6
	SM-G928A	Knox 2.6
	SM-G928F	Knox 2.6
	SM-G928K	Knox 2.6
	SM-G928L	Knox 2.6
	SM-G928N0	Knox 2.6
	SM-G928P	Knox 2.6
	SM-G928R4	Knox 2.6
	SM-G928S	Knox 2.6
	SM-G928T	Knox 2.6
	SM-G928V	Knox 2.6
Galaxy S5	SM-G9008V	Knox 2.3
	SM-G9008W	Knox 2.3
	SM-G900A	Knox 2.3
	SM-G900D	Knox 2.3
	SM-G900F	Knox 2.6
	SM-G900FD	Knox 2.6
	SM-G900H	Knox 2.6
	SM-G900J	Knox 2.3
	SM-G900K	Knox 2.6
	SM-G900L	Knox 2.6
	SM-G900P	Knox 2.6
	SM-G900R4	Knox 2.6
	SM-G900S	Knox 2.6
	SM-G900T	Knox 2.6
	SM-G900T1	Knox 2.6
	SM-G900T3	Knox 2.6
	SM-G900V	Knox 2.3
	SM-G900W8	Knox 2.6
	SM-S902L	Knox 2.1
Galaxy S5 LTE-A	SM-G901F	Knox 2.6
	SM-G906K	Knox 2.6
	SM-G906L	Knox 2.6
	SM-G906S	Knox 2.6
Galaxy S5 Active	SM-G870A	Knox 2.3
	SM-G870D	Knox 2.3
	SM-G870F	Knox 2.3
	SM-G870F0	Knox 2.4.1
	SM-G870W	Knox 2.6
Galaxy S5 mini	SM-G800A	Knox 2.4.1
	SM-G800F	Knox 2.4.1
	SM-G800H	Knox 2.4.1
	SM-G800R4	Knox 2.4.1

Samsung Galaxy smartphones supporting Knox		
Model	Model Number	Knox Version
Galaxy S5 Neo	SM-G903F	Knox 2.6
	SM-G903W	Knox 2.6
Galaxy S5 Sport	SM-G860P	Knox 2.6
Galaxy S4	GT-I9500	Knox 2.3
	GT-I9505	Knox 2.3
	GT-I9506	Knox 2.3
	GT-I9507	Knox 2.3
	GT-I9508	Knox 2.3
	GT-I9508V	Knox 2.3
	SCH-I545	Knox 2.3
	SCH-I545L	Knox 2.3
	SCH-I545PP	Knox 2.3
	SCH-R970	Knox 2.3
	SCH-R970C	Knox 1.x
	SCH-R970X	Knox 2.3
	SGH-I337	Knox 2.3
	SGH-I337M	Knox 2.3
	SGH-I337Z	Knox 1.x
	SGH-M919	Knox 2.1
	SGH-M919N	Knox 2.1
	SGH-M919V	Knox 2.3
	SHV-E300K	Knox 2.3
	SHV-E300L	Knox 2.3
	SHV-E300S	Knox 2.3
SPH-L720	Knox 2.3	
SPH-L720T	Knox 2.3	
Galaxy S4 Active	SGH-I537	Knox 2.3
Galaxy S4 LTE-A	SHV-E330K	Knox 2.3
	SHV-E330L	Knox 2.3
	SHV-E330S	Knox 2.3
Galaxy S4 mini	GT-I9190	Knox 2.0
	GT-I9192	Knox 2.0
	GT-I9195	Knox 2.0
	GT-I9197	Knox 2.0
	SCH-I435	Knox 2.0
	SCH-I435L	Knox 2.0
	SCH-R890	Knox 1.x
	SGH-I257	Knox 2.0
	SGH-I257M	Knox 2.0
	SM-S890L	Knox 1.x
	SPH-L520	Knox 1.x
Galaxy S4 mini Value Edition	GT-I9192I	Knox 2.2
	GT-I9195I	Knox 2.2
Galaxy S4 Value Edition	GT-I9515	Knox 2.3
	GT-I9515L	Knox 2.3

Samsung Galaxy smartphones supporting Knox		
Model	Model Number	Knox Version
Galaxy S3	GT-I9305	Knox 1.x
	GT-I9305N	Knox 1.x
	SCH-I535	Knox 2.0
	SCH-L710	Knox 1.x
	SCH-R530	Knox 1.x
	SCH-R530C	Knox 2.0
	SGH-I747	Knox 1.x
	SGH-I747M	Knox 2.0
	SGH-T999	Knox 1.x
	SGH-T999L	Knox 1.x
	SGH-T999V	Knox 2.0
	SPH_L710	Knox 1.x
	SPH-L710T	Knox 1.x
Galaxy S3 LTE	SHV-E210K	Knox 2.1
	SHV-E210L	Knox 2.1
	SHV-E210S	Knox 2.1
Galaxy Xcover 3	SM-G388D	Knox 2.5
	SM-G388F	Knox 2.4.1
	SM-G389F	Knox 2.6

Samsung Galaxy tablets supporting Knox		
Model	Model Number	Knox Version
Galaxy NotePRO 12.2"	SM-P900	Knox 2.3
	SM-P901	Knox 2.3
	SM-P905	Knox 2.3
	SM-P905F0	Knox 2.3
	SM-P905V	Knox 2.4.1
	SM-P907A	Knox 2.4.1
Galaxy Note 10.1 (2014 Edition)	SM-P600	Knox 2.4.1
	SM-P601	Knox 2.4.1
	SM-P605	Knox 2.4.1
	SM-P605K	Knox 2.0
	SM-P605L	Knox 2.0
	SM-P605S	Knox 2.0
	SM-P605V	Knox 2.4.1
	SM-P607T	Knox 2.4.1
Galaxy Note 10.1"	SHV-E230K	Knox 2.1
	SHV-E230L	Knox 2.1
	SHV-E230S	Knox 2.1
	SHW-M480K	Knox 2.1
	SHW-M480S	Knox 2.1
	SHW-M480W	Knox 2.1

Samsung Galaxy tablets supporting Knox

Model	Model Number	Knox Version
Galaxy Note 8.0"	GT-N5100	Knox 2.0
	GT-N5110	Knox 2.0
	GT-N5120	Knox 2.0
	SGH-I467	Knox 2.0
	SGH-I467M	Knox 2.0
	SHW-M500W	Knox 2.0
Galaxy Tab 4 10.1"	SM-T536	Knox 2.6
	SM-T530	Knox 2.4.1
	SM-T530NU	Knox 2.4
	SM-T531	Knox 2.4
	SM-T533	Knox 2.4
	SM-T535	Knox 2.4
	SM-T537A	Knox 2.4
	SM-T537R4	Knox 2.4
SM-T537V	Knox 2.4	
Galaxy Tab 4 8.0"	SM-T330	Knox 2.4
	SM-T330NU	Knox 2.4
	SM-T331	Knox 2.4
	SM-T332	Knox 2.4
	SM-T335	Knox 2.4
	SM-T335K	Knox 2.4
	SM-T335L	Knox 2.4
	SM-T337A	Knox 2.4
	SM-T337T	Knox 2.4
	SM-T337V	Knox 2.4
Galaxy Tab 4 7.0"	SM-T230NT	Knox 1.x
	SM-T235	Knox 2.4.1
	SM-T237P	Knox 2.4.1
	SM-T237Z	Knox 2.0
Galaxy Tab Active	SM-T360	Knox 2.5
	SM-T365	Knox 2.5
	SM-T365F0	Knox 2.5
	SM-T365Y	Knox 2.5
Galaxy Tab 3 Lite 7.0"	SM-T116IR	Knox 2.5.1
Galaxy Tab 3 7.0"	SM-T217A	Knox 1.x
	SM-T217S	Knox 1.x
	SM-T217T	Knox 2.1
Galaxy Tab A 10.1"	SM-T580	Knox 2.6
	SM-T585	Knox 2.6
	SM-T585N0	Knox 2.6
Galaxy Tab A 9.7"	SM-T550	Knox 2.6
	SM-T555	Knox 2.6
	SM-T555C	Knox 2.3

Samsung Galaxy tablets supporting Knox

Model	Model Number	Knox Version
Galaxy Tab A 9.7" (with S-Pen)	SM-P550	Knox 2.6
	SM-P555	Knox 2.6
	SM-P555C	Knox 2.3
	SM-P555K	Knox 2.6
	SM-P555L	Knox 2.6
	SM-P555S	Knox 2.6
Galaxy Tab A 8.0"	SM-T350	Knox 2.6
	SM-T355	Knox 2.6
	SM-T355Y	Knox 2.6
	SM-T357T	Knox 2.3
	SM-T357W	Knox 2.3
Galaxy Tab A 8.0" (with S-Pen)	SM-P350	Knox 2.6
	SM-P355	Knox 2.6
Galaxy Tab E 9.6"	SM-T560NU	Knox 2.6
	SM-T567V	Knox 2.6
Galaxy Tab E 8.0"	SM-T375L	Knox 2.4.1
	SM-T375S	Knox 2.4.1
	SM-T3777	Knox 2.4.1
	SM-T377A	Knox 2.6
	SM-T377P	Knox 2.6
	SM-T377R4	Knox 2.4.1
	SM-T377T	Knox 2.6
	SM-T377V	Knox 2.6
	SM-T377W	Knox 2.6
Galaxy TabPRO 12.2"	SM-T900	Knox 2.4.1
	SM-T905	Knox 2.4.1
Galaxy TabPRO 10.1"	SM-T520	Knox 1.x
	SM-T525	Knox 1.x
Galaxy TabPRO 8.4"	SM-T320	Knox 1.x
	SM-T321	Knox 1.x
	SM-T325	Knox 1.x
Galaxy Tab S3 9.7"	SM-T813	Knox 2.6
	SM-T819	Knox 2.6
Galaxy Tab S3 8.0"	SM-T713	Knox 2.6
	SM-T719	Knox 2.6
Galaxy Tab Q	SM-T2558	Knox 1.x
Galaxy Tab S2 9.7"	SM-T810	Knox 2.6
	SM-T815	Knox 2.6
	SM-T815C	Knox 2.4
	SM-T815N0	Knox 2.6
	SM-T815Y	Knox 2.6
	SM-T817A	Knox 2.6
	SM-T817P	Knox 2.6
	SM-T817R4	Knox 2.6
	SM-T817T	Knox 2.6
	SM-T817V	Knox 2.6
SM-T817W	Knox 2.6	

Samsung Galaxy tablets supporting Knox

Model	Model Number	Knox Version
Galaxy Tab S2 8.0"	SM-T710	Knox 2.6
	SM-T715	Knox 2.6
	SM-T715C	Knox 2.4
	SM-T715N0	Knox 2.6
Galaxy Tab S 10.5"	SM-T800	Knox 2.3
	SM-T805	Knox 2.3
	SM-T805K	Knox 2.3
	SM-T805L	Knox 2.3
	SM-T805S	Knox 2.3
	SM-T805W	Knox 2.3
	SM-T807A	Knox 2.3
	SM-T807J	Knox 2.3
	SM-T807P	Knox 2.3
	SM-T807R4	Knox 2.3
	SM-T807T	Knox 2.3
	SM-T807V	Knox 2.3
Galaxy Tab S 8.4"	SM-T700	Knox 2.3
	SM-T705	Knox 2.3
	SM-T705C	Knox 2.3
	SM-T705W	Knox 2.3
	SM-T707A	Knox 2.3
	SM-T707D	Knox 2.3
	SM-T707V	Knox 2.3
Galaxy View	SM-T670	Knox 2.5.1
Galaxy W	SM-T255S	Knox 1.x