

Samsung Galaxy smartphones supporting My Knox	
Galaxy A9 (2016), A8, A7 (2016), A7, A5 (2016), A5, A3 (2016), A3	Availability of My Knox may vary depending on your region, mobile service provider, etc.
Galaxy Alpha	
Galaxy E7, E5	
Galaxy Folder	
Galaxy J7, J5 (2016), J5, J3 (2016), J	
Galaxy Note 5, Note 4, Note 3, Note 3 Neo, Note Edge	
Galaxy On7	
Galaxy S7, S7 edge	
Galaxy S6, S6 active, S6 edge, S6 edge+	
Galaxy S5, S5 Active, S5 LTE-A, S5 mini, S5 Neo, S5 Sport	
Galaxy S4	
Galaxy Xcover 3	
心系天下 W2016 (SM-G9198)	
领世旗舰3 (SM-W2016)	
Galaxy Note 10.1 (2014 edition)	
Galaxy Tab 4, Tab A (8.0, 9.7, 10.1), Tab Active, Tab E (8.0), Tab S2 (8.0, 9.7)	

Samsung Galaxy smartphones supporting Knox		
Device	Model Number	Knox Version
Galaxy A9	SM-A9000	Knox 2.6
	SM-A9100	Knox 2.6
	SM-A910F	Knox 2.6
Galaxy A8	SM-A810S	Knox 2.7
	SM-A810F	Knox 2.7
	SM-A810YZ	Knox 2.7
	SM-A8000	Knox 2.6
	SM-A800F	Knox 2.6
	SM-A800I	Knox 2.6
	SM-A800J	Knox 2.6
	SM-A800S	Knox 2.6
	SM-A800YZ	Knox 2.6
Galaxy A7	SM-A7000	< Knox 2.5
	SM-A7009	< Knox 2.5
	SM-A700F	Knox 2.6
	SM-A700FD	Knox 2.6
	SM-A700H	Knox 2.6
	SM-A700K	Knox 2.6
	SM-A700L	Knox 2.6
	SM-A700S	Knox 2.6
	SM-A700YD	< Knox 2.5
	SM-A7100	Knox 2.6
	SM-A710F	Knox 2.6
	SM-A710K	Knox 2.6
	SM-A710L	Knox 2.6
	SM-A710M	Knox 2.6
	SM-A710S	Knox 2.6
SM-A720F	Knox 2.7	

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy A5	SM-A5000	< Knox 2.5
	SM-A5009W	< Knox 2.5
	SM-A500F	Knox 2.6
	SM-A500F1	Knox 2.6
	SM-A500FU	Knox 2.6
	SM-A500H	Knox 2.6
	SM-A500K	Knox 2.6
	SM-A500L	Knox 2.6
	SM-A500M	Knox 2.6
	SM-A500S	Knox 2.6
	SM-A500XZ	< Knox 2.5
	SM-A500Y	Knox 2.6
	SM-A5100	Knox 2.6
	SM-A510F	Knox 2.6
	SM-A510FD	Knox 2.6
	SM-A510K	Knox 2.6
	SM-A510L	Knox 2.6
	SM-A510M	Knox 2.6
	SM-A510S	Knox 2.6
	SM-A520F	Knox 2.7
SM-A520K	Knox 2.7	
SM-A520L	Knox 2.7	
SM-A520S	Knox 2.7	
Galaxy A3	SM-A3000	< Knox 2.5
	SM-A3009	< Knox 2.5
	SM-A300F	< Knox 2.5
	SM-A300FU	Knox 2.6
	SM-A300H	< Knox 2.5
	SM-A300M	< Knox 2.5
	SM-A300XZ	< Knox 2.5
	SM-A300Y	Knox 2.6
	SM-A300YZ	< Knox 2.5
	SM-A310F	Knox 2.6
	SM-A310M	Knox 2.6
	SM-A310N0	Knox 2.6
SM-A320F	Knox 2.7	
Galaxy Ace Style	SM-G357FZ	< Knox 2.5
Galaxy Alpha	SM-G850A	< Knox 2.5
	SM-G850F	< Knox 2.5
	SM-G850K	< Knox 2.5
	SM-G850L	< Knox 2.5
	SM-G850S	< Knox 2.5
	SM-G850W	< Knox 2.5
SM-G850X	< Knox 2.5	
Galaxy C9 / C9 Pro	SM-C9000	Knox 2.7

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy C7 / C7 Pro	SM-C7000	Knox 2.6
	SM-C1010	Knox 2.7
Galaxy C5	SM-C5000	Knox 2.6
Galaxy Core Max	SM-G5108	< Knox 2.5
	SM-G5108Q	< Knox 2.5
	SM-G5109	< Knox 2.5
Galaxy Core Prime	SM-G360BT	< Knox 2.5
	SM-G360F	< Knox 2.5
	SM-G360FY	< Knox 2.5
	SM-G360G	< Knox 2.5
	SM-G360GY	< Knox 2.5
	SM-G360M	< Knox 2.5
Galaxy Core Prime Value Edition	SM-G361F	< Knox 2.5
Galaxy E7	SM-E700F	< Knox 2.5
	SM-E700H	< Knox 2.5
Galaxy E5	SM-E500F	< Knox 2.5
	SM-E500H	< Knox 2.5
Galaxy Express 2	SM-G3815	< Knox 2.5
Galaxy Folder	SM-G150N0	< Knox 2.5
	SM-G150NK	< Knox 2.5
	SM-G150NL	< Knox 2.5
	SM-G150NS	< Knox 2.5
	SM-G155S	< Knox 2.5
	SM-G1600	Knox 2.6
	SM-G9198	< Knox 2.5
Galaxy Golden	SM-W2015	< Knox 2.5
	SM-W2016	Knox 2.5
	SM-W2017	Knox 2.7
Galaxy Grand 2	SM-G7102	< Knox 2.5
	SM-G7105	< Knox 2.5
	SM-G7105L	< Knox 2.5
	SM-G7109	< Knox 2.5
	SM-G710K	< Knox 2.5
	SM-G710L	< Knox 2.5
Grand Prime Plus	SM-G532F	Knox 2.7
	SM-G532G	Knox 2.7
	SM-G532M	Knox 2.7
Galaxy Grand Prime	SM-G5306W	< Knox 2.5
	SM-G5308W	< Knox 2.5
	SM-G5309W	< Knox 2.5
	SM-G530F	< Knox 2.5
	SM-G530FZ	< Knox 2.5
	SM-G530H	< Knox 2.5
	SM-G530P	< Knox 2.5
	SM-G530R4	< Knox 2.5
	SM-G530R7	< Knox 2.5
	SM-G530T	< Knox 2.5
	SM-G530T1	< Knox 2.5
	SM-G530W	< Knox 2.5
SM-G530Y	< Knox 2.5	

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy Grand Prime Value Edition	SM-G531F	< Knox 2.5
	SM-G531M	< Knox 2.5
	SM-G531Y	< Knox 2.5
Galaxy J	SGH-N075T	< Knox 2.5
Galaxy J7	SM-G6100	Knox 2.6
	SM-G610F	Knox 2.6
	SM-J7008	< Knox 2.5
	SM-J700F	Knox 2.6
	SM-J700H	Knox 2.6
	SM-J700K	< Knox 2.5
	SM-J700M	Knox 2.6
	SM-J700P	Knox 2.6
	SM-J700T	Knox 2.6
	SM-J700T1	Knox 2.6
	SM-J7108	Knox 2.5.1
	SM-J7109	Knox 2.5.1
	SM-J710FN	< Knox 2.5
	SM-J710GN	< Knox 2.5
	SM-J710K	< Knox 2.5
	SM-J710MN	< Knox 2.5
	Galaxy J5	SM-J5008
SM-J500F		Knox 2.6
SM-J500FN		Knox 2.6
SM-J500H		Knox 2.6
SM-J500M		< Knox 2.5
SM-J500N0		< Knox 2.5
SM-J500Y		Knox 2.6
SM-J5108		Knox 2.6
SM-J510FN		Knox 2.6
SM-J510GN		Knox 2.6
SM-J510H		Knox 2.6
SM-J510K		Knox 2.6
SM-J510L		Knox 2.6
SM-J510MN		Knox 2.6
SM-J510S	Knox 2.6	
SM-J510UN	Knox 2.6	
Galaxy J3	SM-J3109	Knox 2.7
	SM-J3110	Knox 2.5.1
	SM-J3119	Knox 2.5.1
	SM-J320A	Knox 2.6
	SM-J320AZ	Knox 2.6
	SM-J320N0	Knox 2.6
	SM-J320P	Knox 2.5.1
	SM-J320R4	Knox 2.6
	SM-J320V	Knox 2.6
	SM-J320VPP	Knox 2.6
	SM-J320Y	Knox 2.5.1
	SM-J320YZ	Knox 2.5.1
	SM-J320ZN	Knox 2.5.1
SM-J321AZ	Knox 2.6	
SM-S320VL	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy J2	SM-J200BT	< Knox 2.5
	SM-J200F	< Knox 2.5
	SM-J200G	< Knox 2.5
	SM-J200GU	< Knox 2.5
	SM-J200M	< Knox 2.5
Galaxy J1	SM-J120A	Knox 2.6
	SM-J120AZ	Knox 2.6
	SM-J120F	Knox 2.5.1
	SM-J120FN	Knox 2.5.1
	SM-J120G	Knox 2.5.1
	SM-J120M	Knox 2.5.1
	SM-J120W	Knox 2.6
	SM-J120ZN	Knox 2.5.1
SM-S120VL	Knox 2.6	
Galaxy Mega 6.3	GT-I9200	< Knox 2.5
	GT-I9205	< Knox 2.5
	GT-I9208	< Knox 2.5
	SCH-R960	< Knox 2.5
	SGH-I527	< Knox 2.5
	SGH-I527M	< Knox 2.5
	SHV-E310K	< Knox 2.5
	SHV-E310L	< Knox 2.5
	SHV-E310S	< Knox 2.5
	SPH-L600	< Knox 2.5
Galaxy Mega 2	SM-G7508Q	< Knox 2.5
	SM-G750A	< Knox 2.5
	SM-G750F	< Knox 2.5
	SM-G750H	< Knox 2.5
Galaxy Note 5	SM-N9200	Knox 2.6
	SM-N9208	Knox 2.6
	SM-N920A	Knox 2.6
	SM-N920C	Knox 2.6
	SM-N920K	Knox 2.6
	SM-N920L	Knox 2.6
	SM-N920P	Knox 2.6
	SM-N920R4	Knox 2.6
	SM-N920S	Knox 2.6
	SM-N920T	Knox 2.6
SM-N920V	Knox 2.6	

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy Note 4	SM-N910A	Knox 2.6
	SM-N910C	Knox 2.6
	SM-N910CQ	Knox 2.6
	SM-N910F	Knox 2.6
	SM-N910G	Knox 2.6
	SM-N910H	Knox 2.6
	SM-N910K	Knox 2.6
	SM-N910L	Knox 2.6
	SM-N910P	Knox 2.6
	SM-N910R4	Knox 2.6
	SM-N910S	Knox 2.6
	SM-N910T	Knox 2.6
	SM-N910T2	< Knox 2.5
	SM-N910T3	Knox 2.6
	SM-N910U	Knox 2.6
	SM-N910V	Knox 2.6
	SM-N910W8	Knox 2.6
Galaxy Note 4 S-LTE	SM-N916K	Knox 2.6
	SM-N916L	Knox 2.6
	SM-N916S	Knox 2.6
Galaxy Note 3	SM-N900	< Knox 2.5
	SM-N9005	< Knox 2.5
	SM-N9008	< Knox 2.5
	SM-N9008V	< Knox 2.5
	SM-N900A	< Knox 2.5
	SM-N900J	< Knox 2.5
	SM-N900K	< Knox 2.5
	SM-N900L	< Knox 2.5
	SM-N900P	< Knox 2.5
	SM-N900R4	< Knox 2.5
	SM-N900S	< Knox 2.5
	SM-N900T	< Knox 2.5
	SM-N900V	< Knox 2.5
SM-N900W8	< Knox 2.5	
Galaxy Note 3 Neo	SM-N750	< Knox 2.5
	SM-N7502	< Knox 2.5
	SM-N7505	< Knox 2.5
	SM-N7508V	< Knox 2.5
	SM-N750K	< Knox 2.5
	SM-N750L	< Knox 2.5
	SM-N750S	< Knox 2.5

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy Note 2	GT-N7100	< Knox 2.5
	GT-N7105	< Knox 2.5
	SCH-I605	< Knox 2.5
	SCH-R950	< Knox 2.5
	SGH-I317	< Knox 2.5
	SGH-I317M	< Knox 2.5
	SGH-T889	< Knox 2.5
	SGH-T889V	< Knox 2.5
	SHV-E250K	< Knox 2.5
	SHV-E250L	< Knox 2.5
	SHV-E250S	< Knox 2.5
	SPH-L900	< Knox 2.5
Galaxy Note Edge	SM-N915A	Knox 2.6
	SM-N915D	Knox 2.6
	SM-N915F	Knox 2.6
	SM-N915G	Knox 2.6
	SM-N915FY	Knox 2.6
	SM-N915J	Knox 2.6
	SM-N915K	Knox 2.6
	SM-N915L	Knox 2.6
	SM-N915P	Knox 2.6
	SM-N915R4	Knox 2.6
	SM-N915S	Knox 2.6
	SM-N915T	Knox 2.6
	SM-N915V	Knox 2.6
	SM-N915W8	Knox 2.6
	SM-N915X	< Knox 2.5
Galaxy On7	SM-G600F	Knox 2.6
	SM-G600FY	Knox 2.6
	SM-G600S	Knox 2.6
	SM-G6100	Knox 2.6
	SM-G610F	Knox 2.6
	SM-G610K	Knox 2.6
	SM-G610L	Knox 2.6
	SM-G610S	Knox 2.6
Galaxy On5	SM-G550T	Knox 2.6
	SM-G550T1	Knox 2.6
	SM-G550T2	Knox 2.6
	SM-S550TL	Knox 2.6
	SM-G5510	Knox 2.6
	SM-G5520	Knox 2.6
Galaxy Round	SM-G5700	Knox 2.6
	SM-G910S	< Knox 2.5

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy S7	SM-G9300	Knox 2.6
	SM-G930A	Knox 2.6
	SM-G930F	Knox 2.7.1
	SM-G930K	Knox 2.7.1
	SM-G930L	Knox 2.7.1
	SM-G930P	Knox 2.6
	SM-G930R4	Knox 2.6
	SM-G930S	Knox 2.7.1
	SM-G930T	Knox 2.6
	SM-G930U	Knox 2.6
	SM-G930V	Knox 2.6
	SM-G930W8	Knox 2.6
Galaxy S7 Active	SM-G891A	Knox 2.6
Galaxy S7 edge	SM-G9350	Knox 2.6
	SM-G935A	Knox 2.6
	SM-G935F	Knox 2.7.1
	SM-G935K	Knox 2.7.1
	SM-G935L	Knox 2.7.1
	SM-G935P	Knox 2.6
	SM-G935R4	Knox 2.6
	SM-G935S	Knox 2.7.1
	SM-G935T	Knox 2.6
	SM-G935U	Knox 2.6
	SM-G935V	Knox 2.6
	SM-G935W8	Knox 2.6
Galaxy S6	SM-G9200	Knox 2.6
	SM-G9208	Knox 2.6
	SM-G9209	Knox 2.6
	SM-G920A	Knox 2.6
	SM-G920F	Knox 2.6
	SM-G920FD	Knox 2.6
	SM-G920I	Knox 2.6
	SM-G920K	Knox 2.6
	SM-G920L	Knox 2.6
	SM-G920P	Knox 2.6
	SM-G920R4	Knox 2.6
	SM-G920S	Knox 2.6
	SM-G920T	Knox 2.6
	SM-G920T1	Knox 2.6
	SM-G920V	Knox 2.6
SM-G920W8	Knox 2.6	
Galaxy S6 active	SM-S906L	< Knox 2.5
Galaxy S6 active	SM-G890A	Knox 2.6

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy S6 edge	SM-G9250	Knox 2.6
	SM-G925A	Knox 2.6
	SM-G925F	Knox 2.6
	SM-G925K	Knox 2.6
	SM-G925L	Knox 2.6
	SM-G925P	Knox 2.6
	SM-G925R4	Knox 2.6
	SM-G925S	Knox 2.6
	SM-G925T	Knox 2.6
	SM-G925V	Knox 2.6
	SM-G925W8	Knox 2.6
Galaxy S6 edge+	SM-G9280	Knox 2.6
	SM-G9287	Knox 2.6
	SM-G928A	Knox 2.6
	SM-G928F	Knox 2.6
	SM-G928K	Knox 2.6
	SM-G928L	Knox 2.6
	SM-G928N0	Knox 2.6
	SM-G928P	Knox 2.6
	SM-G928R4	Knox 2.6
	SM-G928S	Knox 2.6
	SM-G928T	Knox 2.6
Galaxy S5	SM-G9008V	Knox 2.6
	SM-G9008W	Knox 2.6
	SM-G900A	Knox 2.6
	SM-G900D	Knox 2.6
	SM-G900F	Knox 2.6
	SM-G900FD	Knox 2.6
	SM-G900H	Knox 2.6
	SM-G900I	Knox 2.6
	SM-G900J	Knox 2.6
	SM-G900K	Knox 2.6
	SM-G900L	Knox 2.6
	SM-G900P	Knox 2.6
	SM-G900R4	Knox 2.6
	SM-G900S	Knox 2.6
	SM-G900T	Knox 2.6
	SM-G900T1	Knox 2.6
	SM-G900T3	Knox 2.6
	SM-G900V	Knox 2.6
	SM-G900W8	Knox 2.6
SM-S902L	< Knox 2.5	

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy S5 LTE-A	SM-G901F	Knox 2.6
	SM-G906K	Knox 2.6
	SM-G906L	Knox 2.6
	SM-G906S	Knox 2.6
Galaxy S5 Active	SM-G870A	Knox 2.6
	SM-G870D	Knox 2.6
	SM-G870F	< Knox 2.5
	SM-G870F0	< Knox 2.5
	SM-G870W	Knox 2.6
Galaxy S5 mini	SM-G800A	< Knox 2.5
	SM-G800F	Knox 2.6
	SM-G800H	Knox 2.6
	SM-G800R4	< Knox 2.5
Galaxy S5 Neo	SM-G903F	Knox 2.6
	SM-G903W	Knox 2.6
Galaxy S5 Sport	SM-G860P	Knox 2.6
Galaxy S4	GT-I9500	< Knox 2.5
	GT-I9505	< Knox 2.5
	GT-I9506	< Knox 2.5
	GT-I9507	< Knox 2.5
	GT-I9508	< Knox 2.5
	GT-I9508V	< Knox 2.5
	SCH-I545	< Knox 2.5
	SCH-I545L	< Knox 2.5
	SCH-I545PP	< Knox 2.5
	SCH-R970	< Knox 2.5
	SCH-R970C	< Knox 2.5
	SCH-R970X	< Knox 2.5
	SGH-I337	< Knox 2.5
	SGH-I337M	< Knox 2.5
	SGH-I337Z	< Knox 2.5
	SGH-M919	< Knox 2.5
	SGH-M919N	< Knox 2.5
	SGH-M919V	< Knox 2.5
	SHV-E300K	< Knox 2.5
	SHV-E300L	< Knox 2.5
	SHV-E300S	< Knox 2.5
SPH-L720	< Knox 2.5	
SPH-L720T	< Knox 2.5	
Galaxy S4 Active	SGH-I537	< Knox 2.5
Galaxy S4 LTE-A	SHV-E330K	< Knox 2.5
	SHV-E330L	< Knox 2.5
	SHV-E330S	< Knox 2.5

Samsung Galaxy smartphones supporting Knox

Device	Model Number	Knox Version
Galaxy S4 mini	GT-I9190	< Knox 2.5
	GT-I9192	< Knox 2.5
	GT-I9195	< Knox 2.5
	GT-I9197	< Knox 2.5
	SCH-I435	< Knox 2.5
	SCH-I435L	< Knox 2.5
	SCH-R890	< Knox 2.5
	SGH-I257	< Knox 2.5
	SGH-I257M	< Knox 2.5
	SM-S890L	< Knox 2.5
	SPH-L520	< Knox 2.5
Galaxy S4 mini Value Edition	GT-I9192I	< Knox 2.5
	GT-I9195I	< Knox 2.5
Galaxy S4 Value Edition	GT-I9515	< Knox 2.5
	GT-I9515L	< Knox 2.5
Galaxy S3	GT-I9305	< Knox 2.5
	GT-I9305N	< Knox 2.5
	SCH-I535	< Knox 2.5
	SCH-L710	< Knox 2.5
	SCH-R530	< Knox 2.5
	SCH-R530C	< Knox 2.5
	SGH-I747	< Knox 2.5
	SGH-I747M	< Knox 2.5
	SGH-T999	< Knox 2.5
	SGH-T999L	< Knox 2.5
	SGH-T999V	< Knox 2.5
	SPH_L710	< Knox 2.5
	SPH-L710T	< Knox 2.5
Galaxy S3 LTE	SHV-E210K	< Knox 2.5
	SHV-E210L	< Knox 2.5
	SHV-E210S	< Knox 2.5
Galaxy Xcover 3	SM-G388D	Knox 2.5
	SM-G388F	< Knox 2.5
	SM-G389F	Knox 2.6

Samsung Galaxy tablets supporting Knox

Device	Model Number	Knox Version
Galaxy NotePRO 12.2"	SM-P900	< Knox 2.5
	SM-P901	< Knox 2.5
	SM-P905	< Knox 2.5
	SM-P905F0	< Knox 2.5
	SM-P905V	< Knox 2.5
	SM-P907A	< Knox 2.5
Galaxy Note 10.1 (2014 Edition)	SM-P600	< Knox 2.5
	SM-P601	< Knox 2.5
	SM-P605	< Knox 2.5
	SM-P605K	< Knox 2.5
	SM-P605L	< Knox 2.5
	SM-P605S	< Knox 2.5
	SM-P605V	< Knox 2.5
SM-P607T	< Knox 2.5	
Galaxy Note 10.1"	SHV-E230K	< Knox 2.5
	SHV-E230L	< Knox 2.5
	SHV-E230S	< Knox 2.5
	SHW-M480K	< Knox 2.5
	SHW-M480S	< Knox 2.5
	SHW-M480W	< Knox 2.5
Galaxy Note 8.0"	GT-N5100	< Knox 2.5
	GT-N5110	< Knox 2.5
	GT-N5120	< Knox 2.5
	SGH-I467	< Knox 2.5
	SGH-I467M	< Knox 2.5
	SHW-M500W	< Knox 2.5
Galaxy Tab 4 10.1"	SM-T530	< Knox 2.5
	SM-T530NU	< Knox 2.5
	SM-T530X	< Knox 2.5
	SM-T531	< Knox 2.5
	SM-T533	< Knox 2.5
	SM-T535	< Knox 2.5
	SM-T536	Knox 2.6
	SM-T537A	< Knox 2.5
	SM-T537R4	< Knox 2.5
	SM-T537V	< Knox 2.5
Galaxy Tab 4 8.0"	SM-T330	< Knox 2.5
	SM-T330X	< Knox 2.5
	SM-T330NU	< Knox 2.5
	SM-T331	< Knox 2.5
	SM-T332	< Knox 2.5
	SM-T335	< Knox 2.5
	SM-T335K	< Knox 2.5
	SM-T335L	< Knox 2.5
	SM-T337A	< Knox 2.5
	SM-T337T	< Knox 2.5
SM-T337V	< Knox 2.5	

Samsung Galaxy tablets supporting Knox

Device	Model Number	Knox Version
Galaxy Tab 4 7.0"	SM-T230NT	< Knox 2.5
	SM-T230NW	Knox 2.6
	SM-T235	< Knox 2.5
	SM-T237P	< Knox 2.5
	SM-T237Z	< Knox 2.5
Galaxy Tab 3 Lite 7.0"	SM-T116IR	Knox 2.5.1
Galaxy Tab 3 7.0"	SM-T217A	< Knox 2.5
	SM-T217S	< Knox 2.5
	SM-T217T	< Knox 2.5
Galaxy Tab Active	SM-T360	Knox 2.5
	SM-T365	Knox 2.5
	SM-T365F0	Knox 2.5
	SM-T365Y	Knox 2.5
Galaxy Tab A 10.1"	SM-P580	Knox 2.6
	SM-P583	Knox 2.6
	SM-P585	Knox 2.6
	SM-P585M	Knox 2.6
	SM-P585N0	Knox 2.6
	SM-P585Y	Knox 2.6
	SM-P587	Knox 2.6
	SM-P588C	Knox 2.6
	SM-T580	Knox 2.6
	SM-T585	Knox 2.6
	SM-T585N0	Knox 2.6
	SM-T587P	Knox 2.6
Galaxy Tab A 9.7"	SM-T550	Knox 2.6
	SM-T555	Knox 2.6
	SM-T555C	Knox 2.6
Galaxy Tab A 9.7" (with S-Pen)	SM-P550	Knox 2.6
	SM-P555	Knox 2.6
	SM-P555C	Knox 2.6
	SM-P555K	Knox 2.6
	SM-P555L	Knox 2.6
	SM-P555S	Knox 2.6
Galaxy Tab A 8.0"	SM-T350	Knox 2.6
	SM-T355	Knox 2.6
	SM-T355Y	Knox 2.6
	SM-T357T	< Knox 2.5
	SM-T357W	< Knox 2.5
Galaxy Tab A 8.0" (with S-Pen)	SM-P350	Knox 2.6
	SM-P355	Knox 2.6
Galaxy Tab E 9.6"	SM-T560NU	Knox 2.6
	SM-T567V	Knox 2.6

Samsung Galaxy tablets supporting Knox

Device	Model Number	Knox Version
Galaxy Tab E 8.0"	SM-T375L	Knox 2.6
	SM-T375S	Knox 2.6
	SM-T3777	< Knox 2.5
	SM-T377A	Knox 2.6
	SM-T377P	Knox 2.6
	SM-T377R4	Knox 2.6
	SM-T377T	Knox 2.6
	SM-T377V	Knox 2.6
	SM-T377W	Knox 2.6
Galaxy TabPRO 12.2"	SM-T900	< Knox 2.5
	SM-T905	< Knox 2.5
Galaxy TabPRO 10.1"	SM-T520	< Knox 2.5
	SM-T525	< Knox 2.5
Galaxy TabPRO 8.4"	SM-T320	< Knox 2.5
	SM-T321	< Knox 2.5
	SM-T325	< Knox 2.5
Galaxy Tab S3 9.7"	SM-T813	Knox 2.6
	SM-T818A	Knox 2.6
	SM-T818T	Knox 2.6
	SM-T818V	Knox 2.6
	SM-T818W	Knox 2.6
	SM-T819	Knox 2.6
Galaxy Tab S3 8.0"	SM-T713	Knox 2.6
	SM-T719	Knox 2.6
Galaxy Tab Q	SM-T2558	< Knox 2.5
Galaxy Tab S2 8.0"	SM-T710	Knox 2.6
	SM-T715	Knox 2.6
	SM-T715C	Knox 2.6
	SM-T715N0	Knox 2.6
Galaxy Tab S2 9.7"	SM-T810	Knox 2.6
	SM-T815	Knox 2.6
	SM-T815C	Knox 2.6
	SM-T815N0	Knox 2.6
	SM-T815Y	Knox 2.6
	SM-T817A	Knox 2.6
	SM-T817P	Knox 2.6
	SM-T817R4	Knox 2.6
	SM-T817T	Knox 2.6
	SM-T817V	Knox 2.6
SM-T817W	Knox 2.6	

Samsung Galaxy tablets supporting Knox

Device	Model Number	Knox Version
Galaxy Tab S 10.5"	SM-T800	Knox 2.6
	SM-T805	Knox 2.6
	SM-T805K	Knox 2.6
	SM-T805L	Knox 2.6
	SM-T805S	Knox 2.6
	SM-T805W	< Knox 2.5
	SM-T807A	Knox 2.6
	SM-T807J	Knox 2.6
	SM-T807P	Knox 2.6
	SM-T807R4	Knox 2.6
	SM-T807T	< Knox 2.5
	SM-T807V	Knox 2.6
Galaxy Tab S 8.4"	SM-T700	Knox 2.6
	SM-T705	Knox 2.6
	SM-T705C	< Knox 2.5
	SM-T705W	< Knox 2.5
	SM-T707A	Knox 2.6
	SM-T707D	Knox 2.6
	SM-T707V	Knox 2.6
Galaxy View	SM-T670	Knox 2.5.1
	SM-T677V	Knox 2.5.1
Galaxy W	SM-T255S	< Knox 2.5